Alphabetical index

7	ч	
,	У	

A/C

Air conditioning filter	.523
Automatic air conditioning	
system	300
ABS	256
ACCESSORY mode	.168
Active stabilizer suspension	
system	256
Adaptive front lighting system	205
AFS	205
Air conditioning system	300
Air conditioning filter	523
Automatic air conditioning	
system	300
Airbags	
Airbag operating conditions	128
Airbag precautions for your	
child	132
Airbag warning light	577
Curtain shield airbag operating	
conditions	129
Curtain shield airbag	
precautions	132
Front passenger occupant	
classification system	137
General airbag precautions	132
Locations of airbags	125
Modification and disposal of	
airbags	136
Proper driving posture123	, 132
Side airbag operating	
conditions	129
Side airbag precautions	132
SRS airbags	125

\larm	119
\ntenna	32
Anti-lock brake system	256
Armrest	.445
\udio input	364
Audio system	
Antenna	32
Audio input	364
AUX port	364
CD player/changer	324
iPod	
MP3/WMA disc	334
Optimal use	36
Portable audio device	364
Radio	314
Steering wheel audio switch	366
USB memory	357
USB port344	, 352
Automatic air conditioning systen	n
Air conditioning filter	523
Automatic air conditioning	
system	300
Automatic headlight leveling	
system	207
Automatic high beam system	
Automatic light control system	
ALIX port	

В	Back door	Child restraint system
	Back door65	Booster seats, definition142
	Wireless remote control59	Booster seats, installation146
	Back-up lights	Convertible seats, definition142
	Replacing light bulbs547	Convertible seats, installation 146
	Wattage649	Front passenger occupant
	Battery	classification system137
	Checking501	Infant seats, definition142
	Hybrid battery	Infant seats, installation146
	(traction battery)31	Installing CRS with LATCH
	If the vehicle has a discharged	system147
	12-volt battery627	Installing CRS with seat belts 149
	Preparing and checking	Installing CRS with top tether
	before winter279	straps153
	Bluetooth [®] audio377	Child safety
	Bluetooth [®] phone389	Airbag precautions132
	Brake	Back door precautions71
	Fluid646	Child restraint system142
	Parking brake182	Child-protectors63
	Brake assist256	How your child should wear
	Break-in tips159	the seat belt94
		Installing child restraints146
	Card key43	Moon roof precautions111
	Care	Power window lock switch105
	Exterior470	Power window precautions 107
	Interior473	Removed electronic key battery
	Seat belts474	precautions527
	Cargo capacity278	Seat belt comfort guide91
	Cargo hooks	Seat belt extender precautions97
	CD changer	Seat belt precautions95
	CD324	Seat heater precautions444
	MP3334	12-volt battery
	WMA disc334	precautions477, 506
	CD player324	
	Charles 270	

Child-protectors63	Doorlock
Cleaning	Back door65
Exterior470	Side door62
Interior473	Wireless remote control59
Seat belts474	Door pockets428
Clock437	Doors
Coat hooks446	Back door65
Compass458	Door lock48, 59, 62
Condenser497	Door windows105
Console box431	Power back door 65
Cooling system	Side door62
Hybrid system overheating630	Side mirrors102
Cornering assist sensors239	Driver's seat belt reminder light 578
Cruise control	Driving
Cruise control223	Break-in tips159
Dynamic radar cruise control227	Correct posture123
Cup holders429	Procedures158
Curtain shield airbags125	Utility vehicle precautions269
Customizable features666	Winter driving tips279
	Driving position memory85
Daytime running light system206	
Defogger	Electric power steering256
Rear window308	Electronic features control192
Side mirrors102	Electronic key
Dimensions638	If the electronic key does not
Dinghy towing297	operate properly624
Display	Electronically modulated air
Energy flow36	suspension246
Multi-information display192	Emergency flashers
Trip information195	Switch566
Warning message585	
Do-it-yourself maintenance483	
Door courtesy lights	
Door courtesy lights423	
Wattage649	
_	

Emergency, in case of		Engine compartment cover	490
If the back door opener is		Engine/power control unit coo	lant
inoperative	70	Capacity	644
If the electronic key does not		Checking	495
operate properly	624	Preparing and checking	
If the hybrid system will		before winter	279
not start	620	Engine oil	
If the shift lever cannot be		Capacity	642
shifted from P	622	Checking	49
If the vehicle has a discharged		Preparing and checking	
12-volt battery	627	before winter	279
If a warning buzzer sounds	576	Engine oil maintenance data	
If a warning light turns on	576	EPS	256
If a warning message is		EV drive mode	176
displayed	585	Event data recorder	574
If you have a flat tire	606		
If you lose your keys	623 F	Floor mat	447
If you think something is		Fluid	
wrong	573	Brake	646
If your vehicle becomes stuck	635	Washer	499
If your vehicle has to be		Fog lights	
stopped in an emergency	636	Replacing light bulbs	547
If your vehicle needs to be		Switch	
towed	567	Wattage	
If your vehicle overheats	630	Footwell light	
Engine		Front fog lights	
Accessory mode	168	Replacing light bulbs	547
Compartment	489	Switch	
Hood	486	Wattage	
How to start the hybrid system	n168	Front passenger occupant	
Identification number	639	classification system	137
If the hybrid system will		Front passenger's seat belt	
not start	620	reminder light	578
Ignition switch	168	Front seats	
Overheating	630	Adjustment	76
"POWER" switch	168	Driving position memory	
		31	

	Flattening seatbacks	77	Heaters	
	Front side marker light		Seat heaters	443
	Replacing light bulbs	547	Side mirrors	
	Wattage		Height control	
	Front turn signal lights		Electronically modulated air	-
	Replacing light bulbs	547	suspension	
	Wattage		Hill-start assist control	
	Fuel		Hood	
	Capacity	640	Hooks	
	Fuel gauge		Cargo	448
	Information		Coat	
	Refueling	112	Horn	
	Туре	650	HUD	
	Fuel door		Hybrid system	
	Fuel filler door	112	Emergency shut off system.	32
	Fuses	528	Energy monitor/consumpti	on
			screen	
G	Garage door opener	452	High voltage components	
	Gauges	184	Hybrid system indicator	
	Glove box	427	"POWER" switch	168
Н	Hands-free system for			482
	mobile phone	389	Identification	
	Hazard lights		Electric motor	639
	Switch	566	Engine	639
	Head restraints		Vehicle	639
	Adjustment	88	Ignition switch	168
	Head-up display	198	Illuminated entry system	423
	Headlight aim		Immobilizer system	117
	Headlight cleaner		Indicator lights	188
	Headlights		Initialization	
	Discharge headlight		Items to initialize	675
	precautions	564	Inside rear view mirror	100
	Replacing light bulbs			
	Switch			
	14	/ 10		

	Interior lights	Lights	
	Interior lights423	Door courtesy lights	423
	Switch424	Emergency flasher switch	
	Wattage649	Fog light switch	
	Š	Hazard light switch	
J	Jack	Headlight switch	
	Positioning a floor jack	Interior light switch	
	Vehicle-equipped jack606	Luggage compartment light	
	Jack handle	Outer foot lights	
	Just Harland	Overhead courtesy light	
K	Keyless entry59	Personal light switch	
IX	Keys	Replacing light bulbs	547
	Electronic key43	Scuff lights	423
	If the electronic key does not	Shift lever light	423
	operate properly624	Turn signal lever	18
	If you lose your keys623	Vanity lights	436
	Key number43	Wattage	649
	Keyless entry59	Load capacity	278
	Keys43	Lock steering column	17
	Mechanical key44	Luggage compartment lights	
	"POWER" switch168	Switch	68
	Wireless remote control key59	Wattage	649
	vvii ciess remote control key	Luggage cover	449
L	Light bulbs	N 4	
	Replacing547	Maintenance	401
	Wattage649	Do-it-yourself maintenance	
		General maintenance	
		Maintenance data	
		Maintenance requirements	4/6
		Meter	405
		Instrument panel light control	
		Meters	184
		Mirrors	40.
		Inside rear view mirror	
		Sida mirrar hastara	308

Side mirrors102

Moon roof.		Vanity mirrors436	PCS	264
Multi-information display Electronic features control 192 Trip information 195 Power easy access system 78 Power outlet 440 "POWER" switch 168 Power windows 105 Pre-collision system 264 Power windows 105 Pre-collision system 264 Power windows 227 Radiator 497 Radio 314 Rear seat Folding down 314 Rear seat Folding down 314 Rear seat Folding down 314 Rear seat entertainment system 81 Seat adjustment 82 Rear view mirror 83 Rear view mirror Compass 458 Rear view mirror Compass 458 Rear view monitor system 252 Rear window defogger 308 Rear window wiper 221 Remote Touch* Replacing lights Seplacing Electronic key battery 526 Fuses 528 Light bullbs 547 Tires 606 Wireless remote control battery 526 Reporting safety defects for 864 Septon 864 Septo		Moon roof108	Personal lights	
Electronic features control 192 Trip information 195		MP3 disc334	Switch	424
Noise from under vehicle		Multi-information display	Power back door	65
Noise from under vehicle		Electronic features control192	Power easy access system	78
Noise from under vehicle		Trip information195		
Pre-collision system			"POWER" switch	168
Pre-collision system	Ν	Noise from under vehicle	Power windows	105
Radiator 227 Radiator 227 Radiator 227 Radiator 497 Radiator 497 Radiator 497 Radio 314 Rear seat Folding down 314 Rear seat Folding down 81 Seat adjustment 81		1 to see it of the direct verification and the see it of t	Pre-collision system	264
Engine oil	0	Odometer185		
Radio		Oil	Radar cruise control	227
Rear seat		Engine oil491	Radiator	497
Fuel filler door		Opener	Radio	314
Hood		Back door65	Rear seat	
Outer foot lights Rear seat entertainment system* Outer foot lights 423 Wattage 649 Outside rear view mirrors Replacing light bulbs 549 Adjusting and folding 102 Wattage 649 Mirror position memory 85 Compass 458 Outside temperature display 438 Rear view mirror 252 Overhead console 433 Rear window defogger 308 Overhead courtesy lights Rear window wiper 221 Overhead courtesy lights 423 Remote Touch* Replacing Electronic key battery 526 Fuses 528 Light bulbs 547 Tires 606 Wireless remote control battery 526 Roof luggage carrier 273 Reporting safety defects for 273		Fuel filler door112	Folding down	81
Outer foot lights 423 Wattage 649 Outside rear view mirrors Wattage 649 Adjusting and folding 102 Rear view mirror Mirror position memory 85 Compass 458 Outside temperature display 438 Rear view monitor system 252 Overhead console 433 Rear window defogger 308 Overhead courtesy lights Rear window wiper 221 Overhead courtesy lights 423 Replacing Wattage 649 Replacing Overheating, Hybrid system 630 Electronic key battery 526 Fuses 528 Light bulbs 547 Tires 606 Wireless remote control battery 526 Replacing light bulbs 547 Switch 203 Reporting safety defects for		Hood486	Seat adjustment	81
Wattage		Outer foot lights	Rear seat entertainment syster	m*
Outside rear view mirrors Wattage		Outer foot lights423	Rear turn signal lights	
Adjusting and folding 102 Rear view mirror Mirror position memory 85 Compass 458 Outside temperature display 438 Rear view monitor system 252 Rear window defogger 308 308 Overhead courtesy lights 423 Rear window wiper 221 Overhead courtesy lights 423 Remote Touch* Replacing Overheating, Hybrid system 630 Electronic key battery 526 Fuses 528 Light bulbs 547 Tires 606 Wireless remote control battery 526 Replacing light bulbs 547 Switch 203 Reof luggage carrier 273 Reporting safety defects for		Wattage649	Replacing light bulbs	549
Mirror position memory		Outside rear view mirrors	Wattage	649
Outside temperature display		Adjusting and folding102	Rear view mirror	
Overhead console 433 Rear window defogger 308 Overhead courtesy lights 423 Rear window wiper 221 Overhead courtesy lights 423 Remote Touch* 8 Wattage 649 Electronic key battery 526 Fuses 528 528 Light bulbs 547 547 Fires 606 Wireless remote control battery 526 Replacing light bulbs 547 526 Switch 203 Reporting safety defects for		Mirror position memory85	Compass	458
Overhead console 433 Rear window defogger 308 Overhead courtesy lights 423 Rear window wiper 221 Overhead courtesy lights 423 Remote Touch* 8 Wattage 649 Electronic key battery 526 Fuses 528 528 Light bulbs 547 547 Tires 606 Wireless remote control battery 526 Replacing light bulbs 547 526 Switch 203 Reporting safety defects for		Outside temperature display438	Rear view monitor system	252
P Parking assist sensors 239 Parking lights 182 Parking lights 547 Switch 203 Wattage 649 Remote Touch* Replacing Electronic key battery 526 Fuses 528 Light bulbs 547 Wireless remote control 547 Switch 203 Wattage 649 Remote Touch* Replacing Electronic key battery 526 Fuses 547 Tires 606 Wireless remote control 526 Roof luggage carrier 273 Reporting safety defects for 273			Rear window defogger	308
Parking assist sensors 239 Parking brake 182 Parking lights Replacing lights Electronic key battery 526 El		Overhead courtesy lights	Rear window wiper	221
Parking assist sensors		Overhead courtesy lights423	Remote Touch*	
Parking assist sensors 239 Light bulbs 547 Tires 606 Wireless remote control battery 526 Roof luggage carrier 273 Reporting safety defects for		Wattage649	Replacing	
Parking assist sensors 239 Parking brake 182 Parking lights Wireless remote control battery Replacing light bulbs 547 Switch 203 Wattage 649 Light bulbs 547 Tires 606 Wireless remote control battery 526 Roof luggage carrier 273 Reporting safety defects for		Overheating, Hybrid system630	Electronic key battery	526
Parking assist sensors			Fuses	528
Parking brake 182 Parking lights Wireless remote control Replacing light bulbs 547 Switch 203 Wattage 649 Tires 606 Wireless remote control battery 727 Roof luggage carrier 273 Reporting safety defects for	Р	Parking assist sensors 239	Light bulbs	547
Parking lights Replacing light bulbs		•	Tires	606
Replacing light bulbs		_	Wireless remote control	
Switch			battery	526
Wattage649 Reporting safety defects for			Roof luggage carrier	273
U.S. owners678			Reporting safety defects for	
			U.S. owners	678

Safety Connect	462
Scuff lights	423
Seat belts	
Adjusting the seat belt	91
Automatic locking retractor	93
Child restraint system	
installation	146
Cleaning and maintaining	
the seat belts	474
Emergency locking retractor	93
How to wear your seat belt	90
How your child should wear	
the seat belt	94
Pregnant women,	
proper seat belt use	
Reminder light	
Seat belt extender	94
Seat belt pretensioners	92
Seat heaters	
Seat position memory	
Seat ventilators	
Seating capacity	278
Seats	
Adjustment	76, 81
Adjustment	
precautions	80, 83
Child seats/child restraint	
system installation	
Cleaning	
Flatting seat backs	
Head restraint	88
Power easy access system	78
Properly sitting in the seat	
Seat heaters	443

Seat position memory	85
Seat ventilators	
Service reminder indicators	
Shift lever	
If the shift lever cannot be	
shifted from P	622
Transmission	173
Shift lever light	423
Shift lock system	622
Side airbags	125
Side marker lights	
Switch	203
Side mirror	
Adjusting and folding	102
Mirror position memory	85
Smart access system with	
push-button start	
Entry function	48
Starting the hybrid system	168
"SOS" button	462
Spare tire	
Inflation pressure	647
Storage location	606
Spark plug	644
Specifications	638
Speedometer	184
Steering	
Column lock release	171
Steering wheel	
Adjustment	98
Audio switches	
Power easy access system	78
Steering wheel position	
memory	85

Storage feature	126	Theft deterrent system	
Stuck vehicle	420	Alarm	110
If your vehicle becomes stuck	635	Immobilizer system	
Sun visors		Theft prevention labels	
Sunshades		Tire inflation pressure	
Switch	109	Tire information	
Display contrast adjustment		Glossary	660
switch	10.0	Size	
Display position adjustment	190	Tire identification number	
switch	108	Uniform tire quality grading	
Driving mode selector switch		Tires	037
Emergency flasher switch		Chains	270
ENTER switch		Checking	
Fog light switch		If you have a flat tire	
Hazard light switch		Inflation pressure	
Head-up display main switch.		Inflation pressure sensor	
Ignition switch		Information	
Light switches		Replacing	
Menu switch		Rotating tires	
Power back door switch		Size	
Power door lock switch		Snow tires	
"POWER" switch	_	Spare tire	
Power window switch		Tire pressure warning	
Rear window wiper and	1	system50)8 578
washer switch	221	Tools	
Window lock switch		Total load capacity	
Wiper and washer switch		Towing	27 0
Triper and trasher stricer	210	Dinghy towing	297
Tellista		Emergency towing	
Tail lights	5 <i>4</i> 7	Trailer towing	
Replacing light bulbs Switch		TRAC	
		Traction control	
Wattage		Trailer towing28	
			.0, 2 .0
Telephone switch	394		

	Transmission	Electronic engine control	
	Hybrid transmission173	system	577
	If the shift lever cannot be	Low fuel level	578
	shifted from P622	Low tire pressure	578
	S mode177	Malfunction indicator lamp	577
	Trip information display192	Master warning light	578
	Trip meter184	Open door	578
	Turn signal lights	Pre-collision system	577
	Replacing light bulbs547	Pretensioners	577
	Switch181	Seat belt reminder light	578
	Wattage649	SRS airbags	577
	-	Tire pressure	578
٧	Vanity lights	Warning messages	585
	Vanity lights436	Washer	
	Wattage649	Checking	499
	Vanity mirrors436	Preparing and checking	
	VDIM256	before winter	279
	Vehicle dynamics integrated	Switch	216
	management256	Washing and waxing	470
	Vehicle identification number 639	Weight	
	Vehicle stability control256	Cargo capacity	278
	Voice command switch394	Load limits	278
	VSC256	Weight	638
		Wheels	521
U W	USB port344, 352	Window glasses	105
		Window lock switch	105
	NA /	Windows	
/ V	Warning buzzers	Power windows	105
	Brake system576	Rear window defogger	308
	Open door578	Washer	216
	Seat belt reminder578	Windshield wiper de-icer	309
	Warning lights	Windshield wipers	216
	Anti-lock brake system577	Wireless remote control key	
	Brake assist system577	Replacing the battery	526
	Brake system576	Wireless remote control	
	Charging system576	WMA disc	334
	Electric power steering577		